

JUKE BOX

CD PLAYER

SATELLITE TELEVISION

KARAOKE

FIRE ALARM SYSTEM

ZX-135

PRIORITY INPUT 3

VIA FRONT PANEL INSERT

OUTPUT 6 OUTPUT 4 OUTPUT 3 OUTPUT 2 OUTPUT 1

LINE 3 R LINE 2 L LINE 1 RIGHT LEFT MIC

DIGITAL I/O

AUDIO I/O

EXTERNAL OVERSPEAK

MONO AMPLIFIER

LOBBY/TOILETS/GARDEN

MONO/STEREO AMPLIFIERS

MONO AMPLIFIER

RESTAURANT

- SOURCE SELECT
- VOLUME
- MUTE

ZX-R2

ZX-PM1

MONO AMPLIFIER


LOUNGE

- VOLUME
- MUTE

ZX-R1

ZX-HUB

- PAGE ANY ZONE
- SOURCE SELECT ANY ZONE
- VOLUME ANY ZONE
- MUTE ANY ZONE



ZX-MR1

MAIN BAR/ENTERTAINMENT AREA

DIGITAL CONTROL NETWORK